


MUSE

M-830 DJ



- FR** Manuel de l'utilisateur
- GB** User Manual
- PT** Manual do Utilizador
- DE** Benutzerhandbuch
- ES** Manual de instrucciones
- IT** Manuale di istruzioni
- NL** Handleiding



UTILISATION
Allumer / éteindre l'unité
Appuyez sur **⏻** pour allumer l'unité. Vous entendrez la voix «Bluetooth». Appuyez de nouveau sur **⏻** pour éteindre l'unité. Vous entendrez la voix «Power off» (extinction).

Le mot **Bluetooth**® ainsi que les marques et logo sont des marques commerciales déposées détenues par Bluetooth SIG, Inc. et l'utilisation de ces marques par New One S.A.S se fait dans le cadre d'une autorisation. Les autres marques et noms commerciaux sont les propriétés de leurs titulaires respectifs.

Coupler un appareil Bluetooth
Appuyez sur **⏻** pour allumer l'unité. L'indicateur de fonction LED clignotera en bleu rapidement pour indiquer qu'il est en mode couplage. Sur l'appareil Bluetooth, activez le Bluetooth et sélectionnez « M-830 DJ » dans la liste des appareils. (consultez le manuel d'instruction de l'appareil pour les détails de connexion). Si l'appareil Bluetooth vous demande un mot de passe, utilisez '0000'. Certains appareils Bluetooth vous demanderont d'accepter la connexion. Si les unités sont couplées correctement, vous entendrez la voix «Connected» (Connecté). L'indicateur de fonction LED clignotera en bleu lentement.

Astuce: Si vous souhaitez connecter votre enceinte Bluetooth à un autre appareil Bluetooth, appuyez sur le bouton **⏻** deux fois pour déconnecter le périphérique, puis suivez les étapes ci-dessus pour établir une nouvelle connexion.

Sur certains appareils, comme les ordinateurs, une fois couplé, vous devez sélectionner l'unité dans le menu Bluetooth et choisir « Utiliser comme un dispositif audio (stéréo) » ou une phrase similaire.

Le couplage reste intact lorsque l'unité et/ou l'appareil Bluetooth sont amenés hors de la portée de liaison. Une connexion active sera rétablie lorsque votre appareil Bluetooth reviendra dans la portée.

Lorsque vous rallumez l'unité, elle essayera automatiquement de se reconnecter avec le dernier appareil Bluetooth connecté.

Utiliser un appareil Bluetooth
1. Avec une unité couplée (voir la section précédente), faites fonctionner votre appareil Bluetooth et il diffusera du son par le biais de l'enceinte M-830 DJ.
2. Appuyez sur la touche **⏻** pour mettre la lecture en pause. Touchez à nouveau pour reprendre la lecture.
3. Tenez les touches **➔ / ➜** appuyées pour régler le volume de son. Vous pouvez également régler le volume sur l'appareil sur lequel vous êtes couplé.
4. Appuyez brièvement sur les touches **➔ / ➜** pour choisir le fichier audio de votre choix.

Utiliser un appareil NFC
NFC (Near Field Communication) est une technologie qui permet la communication sans fil de courte portée entre des appareils compatibles NFC, comme les téléphones portables.

1. Appuyez sur **⏻** pour allumer l'unité. L'indicateur de fonction LED clignotera en bleu pour indiquer qu'il est en mode couplage.
2. Activez le NFC et le Bluetooth sur vos appareils Bluetooth (consultez le manuel d'utilisation de votre appareil pour plus de détails), touchez l'appareil NFC sur le marquage NFC **Ⓜ** de cette unité.
3. Si les unités sont couplées correctement, vous entendrez la voix « Connected » (Connecté). L'appareil NFC est connecté à cette unité via Bluetooth.

Choisissez et lisez un fichier audio ou musical sur votre appareil connecté.
4. Pour interrompre la connexion, touchez l'appareil NFC sur le marquage NFC **Ⓜ** de cette unité à nouveau.

Remarque: La portée opérationnelle entre l'unité principale et un appareil NFC est environ de 10 mètres.

Recevoir un appel / passer un appel
Cette unité est équipée d'un microphone intégré (situé derrière la grille du haut-parleur), qui vous permet de passer ou terminer des appels d'un téléphone portable connecté sur cette unité. Assurez-vous que votre téléphone avec le Bluetooth activé soit connecté à l'unité. Lorsque vous recevez un appel sur le téléphone portable, vous entendrez une tonalité d'appel avant d'entendre sur l'unité.

FR Lire attentivement les instructions avant de faire fonctionner l'appareil.
GB Please read the instruction carefully before operating the unit.
PT Leia este manual com atenção antes de qualquer utilização.
DE Bitte lesen sie dieses handbuch vor dem gebrauch des gerätes sorgfältig durch.
ES Antes de utilizar este aparato, lea atentamente las siguientes instrucciones.
IT Leggere attentamente questo manuale prima di utilizzare l'apparecchio.
NL Lees deze handleiding aandachtig voor u het toestel gebruikt.


ENCENTE PORTABLE BLUETOOTH RESISTANTE AUX PROJECTIONS D'EAU
EMPLACEMENT ET DESCRIPTION DES COMMANDES
1. ⏻ Veille/ Marche
2. ▶▶ Lecture/ Pause
3. ➔ : Pression longue pour diminuer le volume, pression courte pour passer à la piste précédente
4. ➜ : Pression longue pour augmenter le volume, pression courte pour passer à la piste suivante
5. 📞 Accepter un appel/ transférer un appel/ rappeler un numéro/ terminer un appel
6. 📶 Bouton de contrôle de l'éclairage
7. Microphone
8. Indicateur de fonction LED (bleu pour le mode Bluetooth, vert pour le mode entrée auxiliaire, rouge pour le chargement)
9. Haut-parleurs
10. Port de chargement USB pour recharger votre appareil mobile
11. Entrée auxiliaire (AUX IN) (DC IN 5V ⚡= 1A)
12. Port de chargement micro-USB pour charger l'unité (DC IN 5V ⚡= 1A)
13. 🔌 Marquage NFC



1. Appuyez sur la touche **⏻** pour répondre à l'appel entrant.
2. Tenez la touche **⏻** pour terminer l'appel.
3. Pour rejeter l'appel entrant, tenez la touche **⏻**.
4. Pour transférer un appel entre le téléphone portable et l'unité, appuyez sur la touche **📞** pendant un appel.
5. Pour appeler le dernier numéro composé dans la mémoire du téléphone portable, appuyez sur la touche **📞**.

Remarque:
• La fonction rappel n'est pas disponible s'il n'y a pas de fonction d'enregistrement des appels sur votre téléphone portable.
• Ce système ne fonctionnera pas ou risque de mal fonctionner avec certains téléphones portables / lecteurs audio Bluetooth.
• Si la conversation n'est pas claire, essayez de vous rapprocher du microphone (situé derrière la grille du haut-parleur).

COUPLAGE STÉRÉO
Cette fonction vous permet d'obtenir une qualité de son surround stéréo. Elle nécessite deux haut-parleurs Bluetooth M-830 DJ afin d'obtenir une séparation sans fil en deux canaux radio Bluetooth (canaux droit et gauche), par conséquent, vous devez donc acheter deux M-830 DJ.



1. Allumez les deux haut-parleurs Bluetooth M-830 DJ.
2. Lorsque les deux haut-parleurs sont en mode de couplage, maintenez enfoncé le bouton **▶▶** des 2 haut-parleurs Bluetooth qui deviendra le haut-parleur principal (canaux gauche), puis il recherchera et se connectera au haut-parleur secondaire, ils reconnaîtront automatiquement les canaux de gauche et de droite.
3. Ne démontez pas la batterie, ne la chauffez pas à plus de 100°C et ne la jetez pas au feu.
4. Jouez votre chanson et écoutez le son rendu en stéréo.
5. Appuyez sur le bouton **▶▶** de l'un des deux haut-parleurs pour mettre en pause la lecture. Appuyez à nouveau pour reprendre la lecture.
6. Appuyez sur le bouton **▶▶** deux fois de des haut-parleurs principal pour déconnecter le couplage stéréo.

Par la présente, NEW ONE S.A.S déclare que l'appareil " MUSE M-830 DJ " est conforme aux exigences essentielles et autres dispositions pertinentes de la directive 2014/53/EU. La déclaration de conformité peut être consultée sur le site www.muse-europe.com

Utilisation de la lampe / éclairage de couleur
1. En mode veille, appuyez sur **📶** pour allumer l'éclairage de couleur afin d'obtenir un changement de couleur à répétition sous forme de cycle. Appuyez à nouveau sur le bouton pour choisir manuellement les couleurs à la couleur désirée. Maintenez la touche **📶** enfoncée pour régler le réglage.
Remarque: La lampe ne fonctionne pas en mode veille.

2. Lorsque l'appareil est allumé, appuyez plusieurs fois sur la touche **📶** pour sélectionner le mode d'éclairage.
3. La lampe et l'éclairage de couleur sont allumés en même temps et peuvent être réglés indépendamment.
4. Seul l'éclairage de couleur sera allumé et changera selon la musique.
5. Seul la lampe sera allumée et changera selon la musique.
6. Les lumières sont éteintes.

CONNEXION D'UNE SOURCE AUXILIAIRE
1. Appuyez sur **⏻** pour allumer l'unité.
2. Connectez votre source auxiliaire (ex: lecteur mp3) sur la prise **AUX IN** de l'unité (câble non fourni). L'unité passera automatiquement en mode d'entrée auxiliaire. L'indicateur LED de fonctionnement sera vert, indiquant que vous êtes en mode AUX.

Commencez la lecture de l'unité externe et le son émis par l'unité externe sera diffusé par les haut-parleurs du M-830 DJ.
4. Ajustez le volume sonore au niveau désiré.
5. Pour arrêter la lecture, déconnectez le câble audio de la prise d'entrée auxiliaire. L'unité passera automatiquement en mode Bluetooth.

CHARGEMENT USB
Cette unité est équipée d'un port de chargement USB intégré (puissance: 5V ⚡= 1A) pour recharger votre appareil mobile (ex: Smartphone, tablette, etc.). Branchez simplement le câble de chargement USB (non fourni) dans le port de chargement USB et connectez-le sur votre appareil mobile.

RÉSOLUTION DES PROBLÈMES
En cas de problème avec cette unité, vérifiez ce qui suit avant de demander une réparation:

- Pas de courant**
- L'appareil n'est pas allumé, appuyez sur **⏻** pour allumer l'unité.
 - Assurez-vous que l'unité soit chargée.

- Pas de son - général**
- Le volume de l'appareil externe est réglé au minimum, augmentez le volume.
 - Le volume du M-830 DJ est réglé au minimum, augmentez le volume.
 - Le câble audio est branché, débranchez le câble si vous n'utilisez pas la fonction d'entrée auxiliaire.

L'appareil Bluetooth ne peut pas se coupler ou se connecter à l'unité.
• Vous n'avez pas activé la fonction Bluetooth de votre appareil. Consultez le manuel d'utilisation de votre appareil pour activer la fonction Bluetooth.
• L'unité est déjà connectée à un autre appareil Bluetooth; déconnectez cet appareil et réessayez.

Spécifications
BATTERIE RECHARGEABLES
Type de batterie: Batterie Ion-Lithium 7.4V 1800mAh
Tension de chargement: 5V DC 1000mA
Durée de fonctionnement: Environ 8 heures à 50% du volume après chargement complet
Temps de chargement: Environ 6 heures

Bluetooth
Version Bluetooth: 4.2
Bluetooth: 2.402-2.48GHz
Puissance de sortie des RF (fréquences radio): -4.037 dBm
Distance de fonctionnement: Jusqu'à 10 mètres mesurés en espace ouvert (les murs et les structures peuvent affecter la portée de l'appareil)

AVERTISSEMENT:
• Veillez à assurer une ventilation suffisante et ne couvrez pas les orifices de ventilation de l'appareil.
• Ne placez pas de bougie sur ou à proximité de l'appareil.
• Utilisez cet appareil dans des climats tempérés.
• Veillez à ne pas exposer votre appareil aux éclaboussures.
• Prévoyez un espace de 5 cm minimum autour de l'appareil pour assurer une ventilation suffisante.
• Ne placez pas de récipient rempli de liquide, tel qu'un vase, sur l'appareil.

SAFETY INSTRUCTIONS
• Si l'avenir vous désirez vous débarrasser de cet appareil, veuillez noter que les appareils électriques ne doivent pas être jetés avec les ordures ménagères. Renseignez-vous pour connaître le centre de recyclage le plus proche. Consultez les autorités locales ou votre revendeur pour plus de détails (dirigez-vous vers les déchets des équipements électriques et électroniques).

Remarque: Nos emballages peuvent faire l'objet d'une consigne de tri, pour en savoir plus: www.quefairemedesdechets.fr

CONSIGNES DE SECURITE
CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN

ATTENTION: Pour réduire le risque de choc électrique, ne démontez pas l'appareil. Aucune pièce interne n'est réparable par l'utilisateur. Confiez tout entretien à un technicien qualifié.

Le symbole de l'éclair terminé par une foudre à l'intérieur d'un triangle avertit l'utilisateur de la présence d'une « tension dangereuse » dans l'appareil.
• Le point d'exclamation situé à l'intérieur d'un triangle avertit l'utilisateur de la présence d'instructions importantes dans la documentation accompagnant l'appareil.

AVERTISSEMENT:
• Veillez à assurer une ventilation suffisante et ne couvrez pas les orifices de ventilation de l'appareil.
• Ne placez pas de bougie sur ou à proximité de l'appareil.
• Utilisez cet appareil dans des climats tempérés.
• Veillez à ne pas exposer votre appareil aux éclaboussures.
• Prévoyez un espace de 5 cm minimum autour de l'appareil pour assurer une ventilation suffisante.
• Ne placez pas de récipient rempli de liquide, tel qu'un vase, sur l'appareil.

AVERTISSEMENT:
• Si l'avenir vous désirez vous débarrasser de cet appareil, veuillez noter que les appareils électriques ne doivent pas être jetés avec les ordures ménagères. Renseignez-vous pour connaître le centre de recyclage le plus proche. Consultez les autorités locales ou votre revendeur pour plus de détails (dirigez-vous vers les déchets des équipements électriques et électroniques).

Remarque: Nos emballages peuvent faire l'objet d'une consigne de tri, pour en savoir plus: www.quefairemedesdechets.fr

Pairing remains intact when the unit and/or your Bluetooth device is taken out of communication range. An active connection will be re-established when your Bluetooth device returns within range.
• When the unit is turned on again, it will automatically try to reconnect with the most recently paired Bluetooth device.

Using a Bluetooth Device
1. With a unit paired (see previous section), operate your Bluetooth device and its sound will be heard through the M-830 DJ's speakers.
2. Press the **▶▶** button to pause playback. Press again to resume playback.
3. Long press **➔ / ➜** buttons to adjust the volume level. You can also adjust the volume on the device to which you are paired.
4. Short press **➔ / ➜** buttons to select your desired audio file.

Using a NFC Device
NFC (Near Field Communication) is a technology that enables short-range wireless communication between NFC-enabled devices, such as mobile phones.
1. Press **⏻** to turn ON the unit. The function LED indicator will blink blue indicating it's in pairing mode.
2. Enable NFC and Bluetooth on your Bluetooth device (see the user manual of your device for details), tap the NFC device on the NFC tag **Ⓜ** of this unit. If the units are paired properly, you will hear the voice "Connected". The NFC device is connected to this unit via Bluetooth.

RECEIVING/DIALING A PHONE CALL
This unit is equipped with a built-in microphone (located at the front cabinet behind the speaker grill), which allows you to make or end calls of a connected mobile phone through this unit. Make sure your Bluetooth-enabled mobile phone is paired with the unit. When there is an incoming call to the connected mobile phone, you will hear an incoming call alert tone from the unit.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

No Sound – General
• External device's volume is set to minimum; raise volume.
• The M-830DJ's volume is set to minimum; raise volume.
• The audio cable is plugged in. Unplug cable if not using AUX IN function.

The Bluetooth device cannot pair or connect with the unit.
• You have not activated the Bluetooth function of your device. Refer to the user manual of your device to activate Bluetooth function.
• The unit is already connected with another Bluetooth device; disconnect that device and then try again.

RECHARGEABLE BATTERY
Battery Type: 7.4V 1800mAh Lithium Ion Battery
Charging voltage: DC 5V 1000mA
Operating Time: Approx. 8 hours at 50% volume after fully charged
Charging Time: Approx. 6 hours

Bluetooth
Bluetooth Version: 4.2
Bluetooth: 2.402-2.48GHz
RF Output Power: -4.037 dBm
Working Distance: Up to 10 meters measured in open space (wall and structures may affect range of device)

SAFETY INSTRUCTIONS
CAUTION: To reduce the risk of electric shock, do not remove the cover (or back). There are no user serviceable parts inside the unit. Refer all servicing to qualified personnel.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

RECEIVING/DIALING A PHONE CALL
1. Press the **📞** button to answer the incoming call.
2. Press and hold the **📞** button to end call.
3. To reject the incoming call, press and hold the **📞** button.
4. To transfer the sound between the mobile phone and the unit, press the **📞** button during a call.

