



Art-Nr. AD6SW - Connection to an iPhone

Right !




Wrong !



Art-Nr. AD6SW - Connection to a **USB-device**


Right !

blue above



Wrong !

blue below





Competence in electronics since 1968

Art-Nr. AD6SW - Connection to newer Android device,
or other devices to **USB-C**

USB-C is always RIGHT WAY!



You can't do anything wrong with
USB-C no matter how around,
it is always "right" around.



further infos at www.soundmaster.de



Competence in electronics since 1968

Art-Nr. AD6SW - Connection to older Android device
to **Micro-USB**

Right!



contact-
strips above

Wrong!



contact-
strips below

further infos at www.soundmaster.de

Art-Nr. AD6SW - Anschluss an einem iPhone

RICHTIG!




Falsch!



Art-Nr. AD6SW - Anschluss an einem **USB-Gerät**


RICHTIG!

blau oben



Falsch!

blau unten



Art-Nr. AD6SW - Anschluss an neuerem Android-Gerät,
oder andere Geräte an **USB-C**

USB-C ist immer RICHTIG HERUM!



Bei USB-C kann man nichts falsch machen. Egal wie herum, es ist immer „richtig“ herum.



Art-Nr. AD6SW - Anschluss an älteren Android-Gerät
an **Micro-USB**

RICHTIG!



Falsch!

